tempCube!

WHAT IS DATA-LOGGER MODE?

Data-Logger Mode

Data-Logger Mode is when you can start storing your valued temperature and humidity data internally over the time when there are no nearby routers or smartphones for connection. So you can fetch the data using Bluetooth whenever needed.

- ▶ **Switch the mode**
- ▶ **Connect to the Bluetooth**

SELECT MODE :

Go to **Settings Page**

Find "**Select mode**" at the bottom of the page



Click the right arrow

Toggle to **Data-Logger Mode**

Click "**Continue**"

CONNECT BLUETOOTH :

Gently **press the button 3 times** to **configure Data-Logger** mode.

Click '**Connect**'

Please wait till it converts into **Data-Logger** Mode



Don't exit/press reset while connecting



Configured SUCCESSFULLY

Note :

If it has not configured, then your smartphone is not near the tempCube bluetooth range. Please ensure the tempCube and your smart phone are near.



HOW DOES IT WORK?

- Go to **tempCube Homepage**
- Find your **Data-Logger Mode**
- Find your **Last Sync Period** below that



- Tap the '**Sync**' button to get the Last 30 days of data
- Find the last synced **Temperature & Humidity** in the dashboard

TEMPERATURE Range

- Select the temperature synced period (last 30 days)
- You can also set a custom range for the last temperature sync
- View the temperature data in a graph or table and download it
- Find the downloaded data in your smart phone's local storage

HUMIDITY Range

- Select the humidity synced period (last 30 days)
- You can also set a custom range for the last humidity sync
- View the humidity data in a graph or table and download it
- Find the downloaded data in your smart phone's local storage

*Note : In Data-Logger Mode, Real-Time Alerts are not available

SHIFT TO REAL-TIME MODE :

Go to **Settings page**

Find "**Select mode**" at the bottom of the page

Click the right arrow

Toggle to **Real-time Mode**

Click "**Continue**"